

# BiBurst option

## Tunable GHz and MHz Burst with Burst-in-Burst Capability

PHAROS and CARBIDE-CB3 lasers have an option for tunable GHz and MHz burst with burst-in-burst capability – called BiBurst.

In standard mode, a single pulse is emitted at some fixed frequency. In burst mode, the output consists of pulse packets instead of single pulses. Each packet consists of a certain number of equally separated pulses. MHz-Burst contains N pulses with a nanosecond period, GHz-Burst contains P pulses with a picosecond period. If both bursts are used, the equally separated pulse packets contain sub-packets of pulses (burst-in-burst, BiBurst).

PHAROS and CARBIDE lasers with the BiBurst option bring new capabilities to high-tech manufacturing industries such as consumer electronics, integrated photonic chip manufacturing, future display manufacturing, and quantum technologies. The applications include:

- brittle material drilling and cutting
- deep engraving
- selective ablation
- volume modification of transparent materials
- hidden marking
- surface polishing
- surface functionalization

### SPECIFICATIONS

Model		CARBIDE-CB3	PHAROS
GHz Burst	Intra burst pulse period <sup>1)</sup>	440 ± 40 ps	200 ± 40 ps
	Number of pulses, P <sup>2)</sup>	1 – 10	1 – 25
MHz Burst	Intra burst pulse period	≈ 15 ns	
	Number of pulses, N	1 – 10	1 – 9 (7 with FEC <sup>3)</sup> )

<sup>1)</sup> Custom spacing is available on request.

<sup>2)</sup> Maximum number of pulses in a burst depends on the laser repetition rate and the energy. Custom number of pulses is available on request.

<sup>3)</sup> Fast energy control option. Enables formation of any pulse envelope at laser pulse repetition rate.

